

VIAR - Amritsar

Airport details

State	Punjab
Country	India
Region	VI
Elevation	753ft (230m)
Timezone	GMT +5.5
Coordinates	31.70472, 74.80194
Type	land
ICAO code	VIAR
IATA code	ATQ
FAA code	n/a

Runway info

Runway 16 / 34	
length	3682m (12080ft)
bearing	154° / 334°
width	45m (148ft)
surface	asphalt
displacement threshold	380m (1247ft) / 213m (699ft)
blast zone	91m (299ft) / 91m (299ft)

Communication

AMRITSAR TWR	119.700
AMRITSAR TWR	124.350
AMRITSAR TWR	119.700
AMRITSAR TWR	124.350
AMRITSAR TWR	119.700
AMRITSAR TWR	124.350
AMRITSAR TWR	119.700
AMRITSAR TWR	124.350
AMRITSAR APP	119.700
AMRITSAR APP	119.700
AMRITSAR APP	119.700
AMRITSAR APP	119.700

Approach frequencies

ILS-cat-III	34	109.5	18.00mi
3° GS	34	109.5	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
AR	AMRITSAR NDB	1	160.8°	351
AAR	AMRITSAR VOR/DME	1.6	325.4°	115.50
LA	LAHORE VOR/DME	23.3	245.2°	112.70
LA	LAHORE NDB	23.4	245.8°	268
LO	LAHORE NDB	25.7	237°	338
SP	SHEIKHUPURA NDB	41	269.7°	317
PK	PATHANKOT NDB	53.1	57.1°	393
SLT	SIALKOT VOR/DME	54.1	330.6°	113.80
JJU	JAMMU VOR/DME	59.3	2°	113.30

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only