

VTBS - Bangkok - Bangkok Suvarnabhumi Intl

Airport details

State	Samut Prakan Province
Country	Thailand
Region	VT
Elevation	0ft (0m)
Timezone	GMT +7
Coordinates	13.68583, 100.74889
Type	land
ICAO code	VTBS
IATA code	BKK
FAA code	n/a

Runway info

Runway 01R / 19L	
length	4018m (13182ft)
bearing	15° / 195°
width	61m (200ft)
surface	asphalt
blast zone	122m (400ft) / 122m (400ft)
Runway 01L / 19R	
length	3717m (12195ft)
bearing	15° / 195°
width	61m (200ft)
surface	asphalt
blast zone	122m (400ft) / 122m (400ft)

Communication

Bangkok Suvarnabhumi Intl SUARNABHUMI AIRPORT	127.800
Bangkok Suvarnabhumi Intl SUARNABHUMI AIRPORT	127.800
Bangkok Suvarnabhumi Intl SUARNABHUMI AIRPORT	127.800
Bangkok Suvarnabhumi Intl SUARNABHUMI AIRPORT	127.800
Bangkok Suvarnabhumi Intl GND	121.750
Bangkok Suvarnabhumi Intl GND	121.750
Bangkok Suvarnabhumi Intl GND	121.950
Bangkok Suvarnabhumi Intl GND	121.650
Bangkok Suvarnabhumi Intl GND	121.650
Bangkok Suvarnabhumi Intl GND	121.950
Bangkok Suvarnabhumi Intl GND	121.750

Bangkok Suvarnabhumi Intl GND	121.650
Bangkok Suvarnabhumi Intl GND	121.950
Bangkok Suvarnabhumi Intl GND	121.750
Bangkok Suvarnabhumi Intl GND	121.950
Bangkok Suvarnabhumi Intl GND	121.650
Bangkok Suvarnabhumi Intl TWR	119.000
Bangkok Suvarnabhumi Intl TWR	118.200
Bangkok Suvarnabhumi Intl TWR	118.200
Bangkok Suvarnabhumi Intl TWR	119.000
Bangkok Suvarnabhumi Intl TWR	118.200
Bangkok Suvarnabhumi Intl TWR	118.200
Bangkok Suvarnabhumi Intl TWR	119.000
Bangkok Suvarnabhumi Intl TWR	119.000
Bangkok Suvarnabhumi Intl BANGKOK APP CTL	122.350
Bangkok Suvarnabhumi Intl SUARNABHUMI ARR	124.700
Bangkok Suvarnabhumi Intl SUARNABHUMI ARR	124.700
Bangkok Suvarnabhumi Intl BANGKOK APP CTL	122.350
Bangkok Suvarnabhumi Intl BANGKOK APP CTL	124.350
Bangkok Suvarnabhumi Intl BANGKOK APP CTL	124.350
Bangkok Suvarnabhumi Intl BANGKOK APP CTL	124.350
Bangkok Suvarnabhumi Intl BANGKOK APP CTL	122.350
Bangkok Suvarnabhumi Intl SUARNABHUMI ARR	124.700
Bangkok Suvarnabhumi Intl SUARNABHUMI ARR	124.700
Bangkok Suvarnabhumi Intl BANGKOK APP CTL	122.350
Bangkok Suvarnabhumi Intl BANGKOK APP CTL	124.350

Approach frequencies

ILS-cat-II	19L	110.5	18.00mi
ILS-cat-II	01R	110.1	18.00mi
ILS-cat-II	19R	109.5	18.00mi
ILS-cat-II	01L	109.1	18.00mi
3° GS	19L	110.5	18.00mi
3° GS	01R	110.1	18.00mi
3° GS	19R	109.5	18.00mi
3° GS	01L	109.1	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
SVB	SUARNABHUMI (BANGKOK) VOR/DME	1.9	213°	111.40
BKK	BANGKOK VOR/DME	15.3	323.6°	117.70
PB	PRACHIN BURI NDB	44.6	55.2°	201
KPS	KAMPHAENG SAEN (NAKHON PATHOM) NDB	54.5	301.4°	251
UT	U-TAPHAO INTL (RAYONG) NDB	60.9	165.6°	234

Departure and arrival routes

Transition altitude	11000ft
Transition level	13000ft

SID end points	distance	outbound direction
----------------	----------	--------------------

RW01L

ALBO3H	65.6	15°
ROBK3H	49.0	54°
UPKU3H	46.7	62°
DOSB3H	64.3	80°
GORS3H	36.9	106°
RYN3H	76.8	134°
KIGO3H	34.9	170°
REGO3H	101.6	186°
KASN3H	36.5	187°
UKER3H	107.9	204°
HHN3H	78.5	217°
SABI3H	52.5	219°
BONV3H	57.2	273°
PAST3H	75.1	284°
TARE3H	84.4	302°
NUNL3H	106.1	311°
TANG3H	66.2	333°
SEMB3H	78.1	338°
NOBE3H	95.6	357°

RW01R

ALBO3K	65.6	15°
ROBK3K	49.0	54°
UPKU3K	46.7	62°
DOSB3K	64.3	80°
GORS3K	36.9	106°
RYN3K	76.8	134°
KIGO3K	34.9	170°
REGO3K	101.6	186°
KASN3K	36.5	187°
UKER3K	107.9	204°
HHN3K	78.5	217°
SABI3K	52.5	219°

RW19L	BONV3K	57.2	273°
	PAST3K	75.1	284°
	TARE3K	84.4	302°
	NUNL3K	106.1	311°
	TANG3K	66.2	333°
	SEMB3K	78.1	338°
	NOBE3K	95.6	357°
RW19L	ALBO3J	65.6	15°
	ROBK3J	49.0	54°
	UPKU3J	46.7	62°
	DOSB3J	64.3	80°
	GORS3J	36.9	106°
	RYN3J	76.8	134°
	KIGO3J	34.9	170°
	REGO3J	101.6	186°
	KASN3J	36.5	187°
	UKER3J	107.9	204°
	HHN3J	78.5	217°
	SABI3J	52.5	219°
	BONV3J	57.2	273°
	PAST3J	75.1	284°
	TARE3J	84.4	302°
	NUNL3J	106.1	311°
	TANG3J	66.2	333°
	SEMB3J	78.1	338°
	NOBE3J	95.6	357°
RW19R	ALBO3G	65.6	15°
	ROBK3G	49.0	54°
	UPKU3G	46.7	62°
	DOSB3G	64.3	80°
	GORS3G	36.9	106°
	RYN3G	76.8	134°
	KIGO3G	34.9	170°
	REGO3G	101.6	186°
	KASN3G	36.5	187°
	UKER3G	107.9	204°
	HHN3G	78.5	217°
	SABI3G	52.5	219°
	BONV3G	57.2	273°
	PAST3G	75.1	284°
	TARE3G	84.4	302°
	NUNL3G	106.1	311°
	TANG3G	66.2	333°
	SEMB3G	78.1	338°
	NOBE3G	95.6	357°

STAR starting points		distance	inbound direction
RW01 (ALL)			
	LEBI3D	39.3	25°
	WILA3D	58.9	136°
	NORT3D	62.3	174°
	EAST3D	48.8	221°
	DOLN3D	34.4	312°
RW19 (ALL)			
	LEBI3C	39.3	25°
	WILA3C	58.9	136°
	NORT3C	62.3	174°
	EAST3C	48.8	221°
	DOLN3C	34.4	312°

Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
DOLN3C	DOLNI	VHF	right	115 (295)°	> 14000ft	1.0min timed	ICAO rules
DOLN3D	DOLNI	VHF	right	115 (295)°	> 14000ft	1.0min timed	ICAO rules
EAST3C	EASTE	VHF	left	68 (248)°	> 14000ft	1.0min timed	ICAO rules
EAST3C	TERIB	VHF	left	16 (196)°	> 7000ft	1.0min timed	ICAO rules
EAST3D	EASTE	VHF	left	68 (248)°	> 14000ft	1.0min timed	ICAO rules
LEBI3C	LEBIM	VHF	left	180 (0)°	> 14000ft	1.0min timed	ICAO rules
LEBI3D	LEBIM	VHF	left	180 (0)°	> 14000ft	1.0min timed	ICAO rules
NORT3C	NORTA	VHF	right	360 (180)°	> 14000ft	1.0min timed	ICAO rules
NORT3D	NORTA	VHF	right	360 (180)°	> 14000ft	1.0min timed	ICAO rules
WILA3C	WILLA	VHF	right	285 (105)°	> 14000ft	1.0min timed	ICAO rules
WILA3D	WILLA	VHF	right	285 (105)°	> 14000ft	1.0min timed	ICAO rules

*) magnetic outbound (inbound) holding course

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only