

WA88 - Ferndale - Horse Fly

Airport details

State	Washington
Country	United States of America
Region	
Elevation	67ft (20m)
Timezone	GMT -8
Coordinates	48.89289, -122.55684
Type	land
ICAO code	WA88
IATA code	n/a
FAA code	WA88

Runway info

Runway 07 / 25	
length	556m (1824ft)
bearing	89° / 269°
width	20m (66ft)
surface	grass

Communication

No airport communication available for WA88

Nearby beacons

code	identifier	dist	bearing	frequency
HUH	WHATCOM VORTAC	3.2	336.8°	113
XX	ABBOTSFORD NDB	7.8	29.3°	344
WC	WHITE ROCK NDB	10.1	299.6°	332
YPK	PITT MEADOWS VOR	20.3	333.9°	112.40
YVR	VANCOUVER VOR/DME	25.8	287.2°	115.90
VR	VANCOUVER NDB	25.9	299.2°	266
BVS	SKAGIT/BAY VIEW (BURLINGTON) NDB	26	161.9°	240
AP	ACTIVE PASS NDB	28.9	268.5°	378
FHR	FRIDAY HARBOR NDB	29.4	230.8°	284
NUW	WHIDBEY ISLAND (OAK HARBO TACAN	32.5	191°	113.80
YJ	VICTORIA NDB	36.5	253.5°	200
YYJ	VICTORIA VOR/DME	38	259.8°	113.70
CVV	PENN COVE VOR/DME	39.4	194.4°	117.20
MB	MILL BAY (VICTORIA) NDB	41	257.2°	293
AW	WATON (ARLINGTON) NDB	51.6	153.7°	382
NOW	EDIZ HOOK (PORT ANGELES) NDB	56.3	228.3°	338

PAE PAINE (EVERETT) VOR/DME 59.4 163.9° 110.60

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only