

WMKA - Alor Satar - Alor Setar Sultan Abdul Halim

Airport details

State	Kedah
Country	Malaysia
Region	WM
Elevation	15ft (5m)
Timezone	GMT +8
Coordinates	6.19447, 100.40083
Type	land
ICAO code	WMKA
IATA code	AOR
FAA code	n/a

Runway info

Runway 04 / 22	
length	2950m (9678ft)
bearing	42° / 222°
width	46m (151ft)
surface	asphalt
displacement threshold	0m (0ft) / 200m (656ft)
blast zone	60m (197ft) / 0m (0ft)

Communication

Alor Setar Sultan Abdul Halim ALOR STAR GND	121.600
Alor Setar Sultan Abdul Halim ALOR STAR GND	121.600
Alor Setar Sultan Abdul Halim ALOR STAR GND	121.600
Alor Setar Sultan Abdul Halim ALOR STAR GND	121.600
Alor Setar Sultan Abdul Halim ALOR STAR TWR	122.300
Alor Setar Sultan Abdul Halim ALOR STAR TWR	122.300
Alor Setar Sultan Abdul Halim ALOR STAR TWR	122.300
Alor Setar Sultan Abdul Halim ALOR STAR TWR	122.300
Alor Setar Sultan Abdul Halim ALOR STAR APP	122.300
Alor Setar Sultan Abdul Halim ALOR STAR APP	122.300

Alor Setar Sultan Abdul Halim ALOR 122.300
STAR APP
Alor Setar Sultan Abdul Halim ALOR 122.300
STAR APP

Approach frequencies

ILS-cat-I	04	111.7	18.00mi
3° GS	04	111.7	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
VAS	ALOR SETAR VOR/DME	0.5	203.5°	113.60
AT	ALOR STAR NDB	2.7	219.6°	385
VPL	LANGKAWI VOR/DME	40.2	283.7°	114.10
VB	BUTTERWORTH VORTAC	43	180.6°	113.30
HTY	HAT YAI VOR/DME	44.4	358.9°	115.30
BET	BETONG (YALA) VOR/DME	50.7	118.8°	113.10
VP	PENANG VOR/DME	55.5	188.7°	116.20
PT	PATTANI NDB	57	51.5°	201
SK	SONGKHLA NDB	60.8	11.5°	410
SKL	SONGKHLA VOR/DME	60.9	11.5°	113.50

Departure and arrival routes

Transition altitude	11000ft
Transition level	13000ft

SID end points	distance	outbound direction
RW22		
TAMO1B, TAMO1D	20.4	0°
GUTE1B, GUTE1D	25.5	164°
OMBU1B, OMBU1D	55.5	189°
AKMI1D, AKMI1B	65.6	195°
SAGE1D, SAGE1B	24.6	283°
DUBA1B, DUBA1D	21.7	311°
RIGT1D, RIGT1B	32.0	344°

STAR starting points	distance	inbound direction
RW04		
JERA1E	25.6	9°
JERA1G, PAYA1E	55.5	9°
MULO1G, MULO1E	25.4	86°
TAMO1E, TAMO1G	20.4	180°
KARM1G, KARM1E	19.4	202°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only