

X96 - Cruz Bay Seaplane Base - Cruz Bay

Airport details

State	United States Virgin Islands
Country	United States of America
Region	
Elevation	0ft (0m)
Timezone	GMT -4
Coordinates	18.33477, -64.80140
Type	sea base
ICAO code	X96
IATA code	n/a
FAA code	n/a

Runway info

Runway 05 / 23	
length	610m (2001ft)
bearing	40° / 220°
width	114m (375ft)
Runway 08 / 26	
length	519m (1703ft)
bearing	70° / 250°
width	114m (375ft)

Communication

No airport communication available for X96

Nearby beacons

code	identifier	dist	bearing	frequency
STT	SAINT THOMAS VOR/DME	12.7	275.3°	108.60
COY	SAINT CROIX VOR/DME	36.5	170.4°	108.20
ST	PESTE (CHRISTIANSTED) NDB	38.8	187.3°	241

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only