

XU000E - Zhulebino - Zhulebino Heliport

Airport details

State	Moscow
Country	Russian Federation
Region	
Elevation	463ft (141m)
Timezone	GMT +3
Coordinates	55.68723, 37.84129
Type	helipad
ICAO code	XU000E
IATA code	n/a
FAA code	n/a

Communication

No airport communication available for XU000E

Nearby beacons

code	identifier	dist	bearing	frequency
WT	KARTINO NDB	6.1	209.4°	12.150
DM	RAMENSKOYE NDB	8.5	111.9°	581
LP	DME	10.4	124.6°	109.20
D	RAMENSKOYE NDB	11.6	113.1°	11.850
MRN	DME	13.1	86.4°	112.50
RW	MARYINO NDB	13.1	86.4°	493
PS	OSTAFYEVO (OSTAVYEVO) NDB	13.6	235.8°	625
RT	RAMENSKOYE VOR/DME	13.7	113.9°	117.90
BP	CHELOBITYEVO NDB	14	321.6°	680
P	OSTAFYEVO (OSTAVYEVO) NDB	15	240.1°	305
R	RAMENSKOYE NDB	15.2	113.9°	760
DM	DOMODEDOVO (MOSCOW) NDB	15.5	175.1°	320
N	OSTAFYEVO NDB	16.5	243.7°	305
RT	RAMENSKOYE NDB	17.1	114.2°	370
NW	OSTAFYEVO NDB	17.6	245.6°	625
DMD	DOMODEDOVO (MOSCOW) VOR/DME	18.1	166.7°	113.30
DO	DOMODEDOVO (MOSCOW) NDB	18.2	166.4°	659
OB	VNUKOVO (MOSCOW) NDB	18.8	260.9°	852
SX	VNUKOVO (MOSCOW) NDB	19.3	263°	914
WNK	VNUKOVO VOR/DME	20.7	260.4°	113.70
KS	OPALIKHA NDB	20.9	283.6°	565
OPH	DME-ILS	20.9	283.5°	109.70
OE	VNUKOVO (MOSCOW) NDB	21	259.5°	949
BW	SHEREMETYEVO (MOSCOW) NDB	21.1	311.6°	380
AD	SHEREMETYEVO (MOSCOW) NDB	21.3	311.2°	700

B	SHEREMETYEVO (MOSCOW) NDB	21.6	307.4°	770
GT	VNUKOV (MOSCOW) NDB	21.7	260.4°	294
A	SHEREMETYEVO (MOSCOW) NDB	21.8	307.4°	338
LO	KLIMOVSK NDB	22.8	223°	10.050
N	SHEREMETYEVO (MOSCOW) NDB	22.9	300.6°	770
M	SHEREMETYEVO (MOSCOW) NDB	23	300.8°	338
ER	SHEREMETYEVO NDB	23.6	303.9°	794
NL	SHEREMETYEVO (MOSCOW) NDB	23.7	297.8°	380
MR	SHEREMETYEVO (MOSCOW) NDB	23.9	297.7°	700
MR	SHEREMETYEVO (MOSCOW) VOR/DME	24.6	299.6°	114.60
DK	GLOTAYEVO NDB	31.5	184.6°	
GLW	DME	31.5	184.6°	113.50
DR	SKURYGINO NDB	32.8	225°	415
UM	IVANOVSKOYE NDB	33.1	280.6°	405
AO	AKSINYINO NDB	35.5	140°	732
IKO	DME	37.1	348°	113.20
KN	KOSTINO NDB	37.1	348°	642
IKM	DME	40.1	241.1°	111.60
WZ	KAMENKA NDB	40.1	241.2°	230
SW	SAVELOVO NDB	43.1	328.9°	12.850
SWO	DME	43.1	328.9°	111.80

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only