

ZYFY - Fuyuan - Fuyuan Dongji

Airport details

State	Heilongjiang
Country	China
Region	
Elevation	187ft (57m)
Timezone	GMT +8
Coordinates	48.20012, 134.36848
Type	land
ICAO code	ZYFY
IATA code	FYJ
FAA code	n/a

Runway info

Runway 06 / 24	
length	2495m (8186ft)
bearing	61° / 241°
width	46m (151ft)
surface	asphalt
blast zone	62m (203ft) / 61m (200ft)

Communication

Fuyuan Dongji ATIS	128.800
Fuyuan Dongji ATIS	128.800
Fuyuan Dongji ATIS	128.800
Fuyuan Dongji ATIS	128.800
Fuyuan Dongji Tower	118.300
Fuyuan Dongji Tower	118.300
Fuyuan Dongji Tower	118.300
Fuyuan Dongji Tower	118.300
Fuyuan Dongji ARR/DEP	133.000
Fuyuan Dongji ARR/DEP	133.000
Fuyuan Dongji ARR/DEP	133.000
Fuyuan Dongji ARR/DEP	133.000

Nearby beacons

code	identifier	dist	bearing	frequency
IJ	HAIQING NDB	22.8	140.1°	394
MR	VOLOCHAYEVKA NDB	23.2	30.6°	305
WK	DME	23.2	30.7°	112
UF	NOVY (KHABAROVSK) NDB	35.2	69.4°	469

U	NOVY (KHABAROVSK) NDB	36.5	68.8°	950
B	NOVY (KHABAROVSK) NDB	36.6	68.6°	258
HAB	KHABAROVSK VOR/DME	39.4	67.7°	112.30
H	NOVY (KHABAROVSK) NDB	39.9	67.6°	950
HI	NOVY (KHABAROVSK) NDB	41.4	67.2°	469

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only