

LEBB - Bilbao

Airport details

State	Autonomous Community of the Basque Count
Country	Spain
Region	LE
Elevation	136ft (41m)
Timezone	GMT +1
Coordinates	43.30103, -2.92257
Type	land
ICAO code	LEBB
IATA code	BIO
FAA code	n/a

Runway info

Runway 10 / 28

length	1912m (6273ft)
bearing	95° / 275°
width	45m (148ft)
surface	asphalt
displacement threshold	0m (0ft) / 560m (1837ft)
blast zone	144m (472ft) / 0m (0ft)

Runway 12 / 30

length	2591m (8501ft)
bearing	110° / 290°
width	45m (148ft)
surface	asphalt
displacement threshold	0m (0ft) / 459m (1506ft)
blast zone	67m (220ft) / 60m (197ft)

Communication

Bilbao BILBAO ATIS	118.825
Bilbao BILBAO GND	121.700
Bilbao BILBAO ATIS	118.825
Bilbao BILBAO GND	121.700
Bilbao BILBAO ATIS	118.825
Bilbao BILBAO GND	121.700
Bilbao BILBAO ATIS	118.825
Bilbao BILBAO GND	121.700
Bilbao BILBAO TWR	118.500
Bilbao BILBAO TWR	118.500
Bilbao BILBAO TWR	118.500
Bilbao BILBAO TWR	118.500
Bilbao BILBAO APP	127.450

Bilbao BILBAO APP	127.450
Bilbao BILBAO APP	127.450
Bilbao BILBAO APP	127.450
Bilbao BILBAO DEP	128.575
Bilbao BILBAO DEP	128.575
Bilbao BILBAO DEP	128.575
Bilbao BILBAO DEP	128.575

Approach frequencies

ILS-cat-I	30	110.3	18.00mi
ILS-cat-I	12	111.55	18.00mi
3.4° GS	30	110.3	18.00mi
3.1° GS	12	111.55	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
BLV	BILBAO VOR/DME	0.6	284.1°	115.90
B	BILBAO NDB	6.5	302.5°	395
VTA	VITORIA NDB	24.8	146.9°	345
VFD	VITORIA-FORONDA VOR/DME	26.7	154.7°	112.90
VT	VITORIA NDB	30.4	166.6°	308
VRA	VITORIA VOR/DME	34.2	174.2°	116.60
SA	SANTANDER NDB	41.2	278.2°	416
SNR	SANTANDER VOR/DME	43.6	278.6°	115.30
DGO	DOMINGO VOR/DME	50.9	177.1°	112.60
LPA	LOGRONO VOR/DME	56.8	144.6°	115.45
EAG	LOGRONO NDB	57.6	144.4°	399
BUR	BURGOS VOR/DME	64.4	216.1°	111.40

Departure and arrival routes

Transition altitude	6000ft		
SID end points	distance	outbound direction	
RW10			
BISK2R	23.4	16°	
SSN1R	47.7	89°	
PPN1R	63.5	115°	
AMTO2R, AMTO2X	22.3	225°	
CALC3R	17.6	279°	
DOSU2R	28.5	314°	
MAPA2R	23.5	342°	
RW12			
BISK4B	23.4	16°	
SSN2B	47.7	89°	
PPN2G, PPN1H	63.5	115°	

	AMTO4B, AMTO4D	22.3	225°
	CALC4B	17.6	279°
	DOSU3B	28.5	314°
	MAPA3B	23.5	342°
RW28			
	BISK2S	23.4	16°
	SSN1S	47.7	89°
	PPN1S	63.5	115°
	AMTO2S	22.3	225°
	CALC3S	17.6	279°
	DOSU2S	28.5	314°
	MAPA2S	23.5	342°
RW30			
	BISK4A	23.4	16°
	SSN2A, SSN2C	47.7	89°
	PPN2E, PPN2F	63.5	115°
	AMTO4C, AMTO3A	22.3	225°
	CALC5A	17.6	279°
	DOSU3A	28.5	314°
	MAPA3A	23.5	342°

STAR starting points

		distance	inbound direction
RW12			
	SNR3T, SNR3Z	43.6	99°
	DOSU2T, DOSU2Z	28.5	134°
	MAPA2T, MAPA2Z	23.5	162°
	CEGA3T	35.6	295°
	DGO1T	34.2	354°
RW30			
	SNR3K, SNR3Q	43.6	99°
	DOSU3K, DOSU3Q	28.5	134°
	MAPA2Q, MAPA2K	23.5	162°
	DGO1Q, DGO1L, CEGA2Q, CEGA2K	35.6	295°

Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
CEGA2K	ALBIZ	VHF	right	111 (291)°	> 6000ft	DME 4.0mi	ICAO rules
CEGA2Q	SARRA	VHF	right	117 (297)°	> 6000ft	DME 4.0mi	ICAO rules
CEGA3T	BLV	NDB	left	121 (301)°	> 5000ft	DME 6.0mi	ICAO rules
DGO1L	ALBIZ	VHF	right	111 (291)°	> 6000ft	DME 4.0mi	ICAO rules
DGO1Q	SARRA	VHF	right	117 (297)°	> 6000ft	DME 4.0mi	ICAO rules
DGO1T	BLV	NDB	left	121 (301)°	> 5000ft	DME 6.0mi	ICAO rules
DGO1Z	SUNIR	VHF	left	301 (121)°	> 4000ft	DME 4.0mi	ICAO rules
DGO2X	ROSTO	VHF	left	304 (124)°	> 4000ft	DME 4.0mi	ICAO rules
DOSU2T	SUNIR	VHF	left	301 (121)°	> 4000ft	DME 4.0mi	ICAO rules
DOSU2Z	ROSTO	VHF	left	304 (124)°	> 4000ft	DME 4.0mi	ICAO rules

DOSU3K	ALBIZ	VHF	right	111 (291)°	> 6000ft	DME 4.0mi	ICAO rules
DOSU3Q	SARRA	VHF	right	117 (297)°	> 6000ft	DME 4.0mi	ICAO rules
MAPA2Q	SARRA	VHF	right	117 (297)°	> 6000ft	DME 4.0mi	ICAO rules
MAPA2T	SUNIR	VHF	left	301 (121)°	> 4000ft	DME 4.0mi	ICAO rules
MAPA2Z	ROSTO	VHF	left	304 (124)°	> 4000ft	DME 4.0mi	ICAO rules
SNR3K	ALBIZ	VHF	right	111 (291)°	> 6000ft	DME 4.0mi	ICAO rules
SNR3Q	SARRA	VHF	right	117 (297)°	> 6000ft	DME 4.0mi	ICAO rules
SNR3T	SUNIR	VHF	left	301 (121)°	> 4000ft	DME 4.0mi	ICAO rules
SNR3Z	ROSTO	VHF	left	304 (124)°	> 4000ft	DME 4.0mi	ICAO rules

*) magnetic outbound (inbound) holding course

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only