

# BIAR - Akureyri

---

## Airport details

State	Northeastern Region (Iceland)
Country	Iceland
Region	BI
Elevation	4ft (1m)
Timezone	GMT +0
Coordinates	65.65667, -18.07195
Type	land
ICAO code	BIAR
IATA code	AEY
FAA code	n/a

## Runway info

Runway 01 / 19	
length	2394m (7854ft)
bearing	349° / 169°
width	45m (148ft)
surface	asphalt

## Communication

Akureyri TWR	118.200
Akureyri TWR	118.200
Akureyri TWR	118.200
Akureyri TWR	118.200
Akureyri RADAR	118.700
Akureyri RADAR	118.700
Akureyri RADAR	118.700
Akureyri RADAR	118.700

## Approach frequencies

LOC	01	111.9	18.00mi
ILS-cat-I	01	108.9	18.00mi
ILS-cat-I	19	110.5	18.00mi
5.3° GS	01	108.9	18.00mi
3.4° GS	19	110.5	18.00mi

## Nearby beacons

code	identifier	dist	bearing	frequency
MOB	MOB TACAN	1.2	168.8°	114.80

OE	ODDEYRI (AKUREYRI) NDB	1.7	349.1°	415
KN	KRISTNES (AKUREYRI) NDB	4.2	169.3°	364
AR	AKUREYRI NDB	5.9	349.9°	334
AKI	AKUREYRI VOR/DME	6.4	33.3°	113.60
TO	TORFUR (AKUREYRI) NDB	9.5	206.8°	324
HJ	HJALTEYRI (AKUREYRI) NDB	12	328.4°	319
GA	GARDUR (HUSAVIK) NDB	20	70°	377
NB	BOTN (AKUREYRI) NDB	20.6	213.8°	387
HS	HUSAVIK NDB	22.5	66.8°	329

## Departure and arrival routes

Transition altitude 7000ft

<b>SID end points</b>	<b>distance</b>	<b>outbound direction</b>
RW01		
UTIS2A	22.5	73°
MAME1A	18.1	87°
ASKU1B, ASKU1A	31.7	233°
PERU1A, PERU1B	25.5	256°
RW19		
RETU1D	13.1	105°
JARI1C, JARI1D, JARI1E	27.1	170°
ASKU1D, ASKU1C, ASKU1E	31.7	233°
PERU1D	25.5	256°

<b>STAR starting points</b>	<b>distance</b>	<b>inbound direction</b>
RW19		
PERU1N	25.5	76°
AFPA1M	20.2	100°
BEZI1M	25.5	117°
CUBA1M	29.6	142°
DORF1M	28.7	160°
UTIS1N, UTIS1M	22.5	253°
MAME1M, MAME1N	18.1	267°
PEXI1N, PEXI1M	15.1	355°

## Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only