

CYLW - Kelowna

Airport details

State	British Columbia
Country	Canada
Region	CY
Elevation	1409ft (429m)
Timezone	GMT -8
Coordinates	49.96142, -119.38074
Type	land
ICAO code	CYLW
IATA code	YLW
FAA code	YLW

Runway info

Runway 16 / 34	
length	2723m (8934ft)
bearing	172° / 352°
width	61m (200ft)
surface	asphalt
displacement threshold	371m (1217ft) / 124m (407ft)
blast zone	27m (89ft) / 0m (0ft)

Communication

Kelowna ATIS	127.500
Kelowna ATIS	127.500
Kelowna ATIS	127.500
Kelowna ATIS	127.500
Kelowna GND	121.700
Kelowna GND	121.700
Kelowna GND	121.700
Kelowna GND	121.700
Kelowna TWR	119.600
Kelowna TWR	119.600
Kelowna TWR	119.600
Kelowna TWR	119.600

Approach frequencies

ILS-cat-I	16	111.3	18.00mi
3.2° GS	16	111.3	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
EX	RUTLAND (KELOWNA) NDB	1.3	166.5°	374
LW	KELOWNA NDB	6.1	340.2°	257
YWB	WESTBANK (KELOWNA) NDB	13.2	238.8°	389
UNT	NARAMATA (PENTICTON) NDB	23.5	211.3°	312
6K	VERNON NDB	23.7	17.2°	302
YYF	PENTICTON NDB	29.7	205°	290
ON	OKANAGAN (PENTICTON) NDB	37.8	196.9°	356
V6	SALMON ARM NDB	43.8	11.4°	280
YNY	DME	46.2	31.6°	115.20
YDC	PRINCETON VOR/DME	51.9	239.7°	113.90

Departure and arrival routes

Transition altitude	18000ft
Transition level	18000ft

SID end points	distance	outbound direction
RW16		
NOTIV3	46.2	32°
YDC2	51.9	240°
MRYT2	61.0	269°
RW34		
NOTIV3	46.2	32°
YDC2	51.9	240°
MRYT2	61.0	269°

STAR starting points	distance	inbound direction
RW16		
PIGLU4	18.5	76°
SEKAB4	14.7	108°
NORIP4	15.6	237°
RW34		
PIGLU4	18.5	76°
SEKAB4	14.7	108°
NORIP4	15.6	237°

Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
NORIP4	NORIP	VHF	left	56 (236)°		1.0min timed	ICAO rules
NORIP4	VILMO	VHF	right	330 (150)°		1.0min timed	ICAO rules
PIGLU4	VILMO	VHF	right	330 (150)°		1.0min timed	ICAO rules
PIGLU4	VIVEK	VHF	left	256 (76)°		1.0min timed	ICAO rules
SEKAB4	VILMO	VHF	right	330 (150)°		1.0min timed	ICAO rules

SEKAB4 VIVEK VHF left 256 (76)°

1.0min timed ICAO rules

*) magnetic outbound (inbound) holding course

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only