

# FVFA - Victoria Falls - Victoria Falls Intl

---

## Airport details

State	Matabeleland North Province
Country	Zimbabwe
Region	FV
Elevation	3490ft (1064m)
Timezone	GMT +2
Coordinates	-18.09417, 25.84000
Type	land
ICAO code	FVFA
IATA code	VFA
FAA code	n/a

## Runway info

Runway 12 / 30	
length	3998m (13117ft)
bearing	109° / 289°
width	45m (148ft)
surface	asphalt
blast zone	60m (197ft) / 70m (230ft)

## Communication

Victoria Falls Intl FALLS TWR	121.100
Victoria Falls Intl FALLS TWR	121.100
Victoria Falls Intl FALLS TWR	121.100
Victoria Falls Intl FALLS TWR	121.100
Victoria Falls Intl FALLS APP	121.100
Victoria Falls Intl FALLS APP	121.100
Victoria Falls Intl FALLS APP	121.100
Victoria Falls Intl FALLS APP	121.100

## Approach frequencies

ILS-cat-II	12	110.7	18.00mi
3° GS	12	110.7	18.00mi

## Nearby beacons

code	identifier	dist	bearing	frequency
VFA	VICTORIA FALLS VOR/DME	1.4	279.1°	116.70
FO	VICTORIA FALLS NDB	4.7	286.5°	256
LZ	HARRY NKUMBULA NDB	16.6	350.5°	308

VLI	HARRY NKUMBULA VOR/DME	16.9	355.9°	112.50
MT	MATETSI NDB	25.1	170.7°	260
KAV	KASANE VOR/DME	41.4	291.2°	113.30
KAS	KASANE NDB	42.3	291.6°	287

## Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
MT1A	MT	FIX	right	170 (350)°	5000ft - 14000ft	1.0min timed	230

\*) magnetic outbound (inbound) holding course

## Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

## To be used with X-Plane simulation only