

# KFAT - Fresno - Fresno Air Terminal

---

## Airport details

State	California
Country	United States of America
Region	K2
Elevation	333ft (101m)
Timezone	GMT -8
Coordinates	36.78380, -119.71906
Type	land
ICAO code	KFAT
IATA code	FAT
FAA code	FAT

## Runway info

Runway 11R / 29L	
length	2440m (8005ft)
bearing	120° / 300°
width	46m (150ft)
surface	asphalt
blast zone	255m (837ft) / 255m (837ft)
Runway 11L / 29R	
length	2905m (9531ft)
bearing	120° / 300°
width	46m (150ft)
surface	asphalt
displacement threshold	0m (0ft) / 95m (312ft)
blast zone	255m (837ft) / 255m (837ft)

## Communication

Fresno Air Terminal ATIS	121.350
Fresno Air Terminal ATIS	121.350
Fresno Air Terminal ATIS	121.350
Fresno Air Terminal ATIS	121.350
Fresno Air Terminal GROUND	121.700
Fresno Air Terminal GROUND	121.700
Fresno Air Terminal GROUND	121.700
Fresno Air Terminal GROUND	121.700
Fresno Air Terminal TWR	118.200
Fresno Air Terminal TWR	118.200
Fresno Air Terminal TWR	118.200
Fresno Air Terminal TWR	118.200
Fresno Air Terminal APPROACH	132.200
Fresno Air Terminal APPROACH	132.200

Fresno Air Terminal APPROACH	132.200
Fresno Air Terminal APPROACH	132.200
Fresno Air Terminal DEPARTURE	132.200
Fresno Air Terminal DEPARTURE	132.200
Fresno Air Terminal DEPARTURE	132.200
Fresno Air Terminal DEPARTURE	132.200

## Approach frequencies

LOC	11L	111.3	18.00mi
ILS-cat-III	29R	111.3	18.00mi
3° GS	29R	111.3	18.00mi

## Nearby beacons

code	identifier	dist	bearing	frequency
CZQ	CLOVIS (FRESNO) VORTAC	7.6	316.2°	112.90
FRA	FRIANT VORTAC	20.1	21°	115.60
VIS	VISALIA VOR/DME	27.4	150.3°	109.40
NLC	NAVY LEMOORE TACAN	28.9	209.3°	113.30
HYP	EL NIDO (MERCED) VOR/DME	41.8	302.6°	114.20
TTE	TULE VOR/DME	62.2	141.2°	109.20

## Departure and arrival routes

Transition altitude	18000ft
Transition level	18000ft

SID end points	distance	outbound direction
RW11 (ALL)		
OAL4	118.3	58°
BULL3, YOSE3	83.4	255°
RW29 (ALL)		
OAL4	118.3	58°
BULL3, YOSE3	83.4	255°

STAR starting points	distance	inbound direction
RW11L		
ALTTA9	62.2	321°
RW29R		
ALTTA9	62.2	321°

# Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

## To be used with X-Plane simulation only