

MMGL - Guadalajara - Don Miguel Hidalgo Intl

Airport details

State	Jalisco
Country	Mexico
Region	MM
Elevation	5012ft (1528m)
Timezone	GMT -6
Coordinates	20.53156, -103.30261
Type	land
ICAO code	MMGL
IATA code	GDL
FAA code	n/a

Runway info

Runway 10 / 28	
length	4001m (13127ft)
bearing	113° / 293°
width	60m (197ft)
surface	asphalt
blast zone	58m (190ft) / 61m (200ft)
Runway 02 / 20	
length	1811m (5942ft)
bearing	32° / 212°
width	30m (100ft)
surface	asphalt
displacement threshold	0m (0ft) / 303m (994ft)
blast zone	26m (85ft) / 0m (0ft)

Communication

Don Miguel Hidalgo Intl ATIS	127.900
Don Miguel Hidalgo Intl ATIS	127.900
Don Miguel Hidalgo Intl ATIS	127.900
Don Miguel Hidalgo Intl ATIS	127.900
Don Miguel Hidalgo Intl CLRS	132.800
Don Miguel Hidalgo Intl CLRS	132.800
Don Miguel Hidalgo Intl CLRS	132.800
Don Miguel Hidalgo Intl CLRS	132.800
Don Miguel Hidalgo Intl GND	121.900
Don Miguel Hidalgo Intl GND	121.900
Don Miguel Hidalgo Intl GND	121.900
Don Miguel Hidalgo Intl GND	121.900
Don Miguel Hidalgo Intl TWR	118.100
Don Miguel Hidalgo Intl TWR	118.100

Don Miguel Hidalgo Intl TWR	118.100
Don Miguel Hidalgo Intl TWR	118.100
Don Miguel Hidalgo Intl APP	119.300
Don Miguel Hidalgo Intl APP	119.300
Don Miguel Hidalgo Intl APP	119.300
Don Miguel Hidalgo Intl APP	119.300
Don Miguel Hidalgo Intl DEP	119.300
Don Miguel Hidalgo Intl DEP	119.300
Don Miguel Hidalgo Intl DEP	119.300
Don Miguel Hidalgo Intl DEP	119.300

Approach frequencies

ILS-cat-I	10	110.1	18.00mi
ILS-cat-I	28	111.3	18.00mi
3° GS	10	110.1	18.00mi
2.8° GS	28	111.3	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
GDL	GUADALAJARA VOR/DME	0.7	227.8°	117.30
GD	DON MIGUEL HIDALGO INTL(GUADAL NDB	8.1	116.2°	395
ZAP	ZAPOPAN VOR/DME	15.9	323.3°	113.40

Departure and arrival routes

Transition altitude	18500ft
Transition level	19500ft

SID end points	distance	outbound direction
RW10		
OTOK1A	49.0	14°
GOYA3A	36.4	14°
PIRAR3	29.3	54°
FEIS1A	45.6	54°
XORID2	29.3	76°
KARUN1	29.4	89°
KELV1A	55.1	92°
LONK1D	49.6	107°
OVALI4	29.6	107°
EBDEG1	40.0	132°
EMIR1A	60.1	135°
LEROK3	25.2	149°
TABG3A	40.7	193°
EMIG2A	30.7	223°
NOTU1D	56.6	289°

RW28	SEDE1A	50.1	312°
	OTOK1B	49.0	14°
	GOYA3B	36.4	14°
	FEIS1B	45.6	54°
	KELV1B	55.1	92°
	LONK1E	49.6	107°
	EMIR1B	60.1	135°
	TABG3B	40.7	193°
	EMIG2B	30.7	223°
	DEBRO2	30.5	260°
	DUNSU2	35.4	274°
	NUBIG2	30.2	288°
	NOTU1E	56.6	289°
	TIKIT3	30.1	300°
	TEILA3	30.0	311°
	SEDE1B	50.1	312°

STAR starting points	distance	inbound direction
RW10		
USB11C	57.0	57°
LIPE1F	54.8	95°
LONV1C	49.8	161°
LIVR1C	49.4	220°
MODE1A	52.6	256°
ULUV1A	59.9	304°
RW28		
USB11D	57.0	57°
LIPE1G	54.8	95°
LONV1D	49.8	161°
LIVR1D	49.4	220°
MODE1B	52.6	256°
ULUV1B	59.9	304°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only