

# WAJJ - Jayapura-papua Island - Jayapura Sentani

---

## Airport details

State	Papua
Country	Indonesia
Region	WA
Elevation	289ft (88m)
Timezone	GMT +9
Coordinates	-2.57570, 140.51811
Type	land
ICAO code	WAJJ
IATA code	DJJ
FAA code	n/a

## Runway info

Runway 12 / 30	
length	3002m (9849ft)
bearing	127° / 307°
width	45m (148ft)
surface	asphalt
blast zone	60m (197ft) / 186m (610ft)

## Communication

Jayapura Sentani ATIS	126.250
Jayapura Sentani ATIS	128.800
Jayapura Sentani ATIS	126.250
Jayapura Sentani ATIS	128.800
Jayapura Sentani ATIS	126.250
Jayapura Sentani ATIS	128.800
Jayapura Sentani ATIS	126.250
Jayapura Sentani ATIS	128.800
Jayapura Sentani TWR	118.100
Jayapura Sentani TWR	118.100
Jayapura Sentani TWR	118.100
Jayapura Sentani TWR	118.100
Jayapura Sentani JAYAPURA APP	119.100
Jayapura Sentani JAYAPURA APP	119.100
Jayapura Sentani JAYAPURA APP	119.100
Jayapura Sentani JAYAPURA APP	119.100

## Approach frequencies

ILS-cat-I	30	110.3	18.00mi
-----------	----	-------	---------

3° GS      30      110.3      18.00mi

## Nearby beacons

code	identifier	dist	bearing	frequency
JPA	JAYAPURA VOR/DME	0.1	208.3°	116.20
VNO	VANIMO NDB	47.5	97.4°	257

## Departure and arrival routes

Transition altitude      18000ft  
Transition level      18000ft

SID end points	distance	outbound direction
RW12		
VANK1A	30.2	107°
MELA1A	101.3	178°
MALI1A	100.2	226°
TIST1A	99.9	240°
KUBI1A	99.4	287°

STAR starting points	distance	inbound direction
RW30		
MALI2B	100.2	46°
TIST2B	99.9	60°
KUBI2B	99.4	107°
VANK2B	30.2	287°
MELA2B	101.3	358°

## Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
KUBI2B	TOARE	VHF	left	123 (303)°	> 4000ft	1.0min timed	ICAO rules
MALI2B	TOARE	VHF	left	123 (303)°	> 4000ft	1.0min timed	ICAO rules
MELA2B	TOARE	VHF	left	123 (303)°	> 4000ft	1.0min timed	ICAO rules
TIST2B	TOARE	VHF	left	123 (303)°	> 4000ft	1.0min timed	ICAO rules
VANK2B	TOARE	VHF	left	123 (303)°	> 4000ft	1.0min timed	ICAO rules

\*) magnetic outbound (inbound) holding course

## Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only